



CARGO LINER

PT #2332

INSTALLATION AND CARE AND USE INSTRUCTIONS

Thank you for selecting a Cargo Liner from Husky Liners. Your cargo liner is custom molded to fit your vehicle. Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates the “flattening” process will take longer; moving the liner to a heated area will accelerate the process. Place the liner in the cargo area, if you would like access to your tie down locations, please trim the inner part of the 4 oval located at each corner.

Your liner is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409[®] or glass plus[®] work well. Use of armor all[®], son-of-a-gun[®] or similar items is discouraged as these products make the liner slick.



TO ACCESS CARGO TIE DOWNS, TRIM AWAY
MATERIAL INSIDE OF THE RAISED RIB (4 PLACES).



CARGO LINER

PT #2332